



*Great sound
from Barcelona
since 1972*

www.amateaudio.com

User's manual

S6LP

NÍTiD

#purelynitid

April 2024

Amate Audio S.L.

EXPORT & CUSTOMER SERVICE
Perpinyà, 25 · Polígon Industrial Nord
08226 Terrassa · Barcelona – SPAIN
T. +34 93 735 65 65
export@amateaudio.com

R&D, FACTORY AND MANAGEMENT
Violinista Vellsolà, 18
08222 Terrassa · Barcelona – SPAIN
T. +34 93 736 23 90
info@amateaudio.com

Safety Instructions

1. All safety instructions must be read before using this device.
2. Keep and follow these instructions
3. Heed all warnings
4. The exclamation mark in the triangle indicates internal components which if replaced can affect safety.
5. The lightning symbol within the triangle indicates the presence of dangerous uninsulated voltages.
6. Only clean the device with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install the device near heat sources such as radiators, heaters or other heat-emitting elements.
9. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus
10. The equipment must be repaired by qualified technical service personnel when:
 - A. The mains supply cable is damaged, or
 - B. Any object or liquid has damaged the device; or
 - C. The equipment does not function normally or correctly; or
 - D. The equipment has been exposed to the rain; or
 - E. The chassis is damaged
11. Disconnect the device in the case of electric storms or during long periods of disuse.
12. **WARNING** – To reduce the risk of fire or electric shock, do not expose this device to rain or moisture
13. The equipment shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the device.
14. For hanging and installation, use manufacturer recommended accessories only.

1. INTRODUCTION

1.1. General

Amate Audio would like to thank you for your confidence in our NÍTID Series. We suggest you to carefully read the following instructions in order to obtain the best results in performance.

1.2. Features and presentation

S6LP

- Passive acoustic system
- NL4MP Speakon input & parallel output
- 200 W program power
- Sensitivity 1 W / 1 m: 92 dB
- 1 x 6" neodymium magnet woofer with 1.5" voice coil and fibre cone
- 1" PEN diaphragm neodymium magnet compression driver
- 70° (H) x 70° (V) dispersion horn
- 8Ω and 16Ω available

2. CONNECTIONS

2.1. Connection description

A) SPEAKON: The S6LP uses two NL4MP Speakon terminals and are duly prepared for a perfect connection in a parallel system. Terminal Pins +1/-1 must be always used, disregarding the +2/-2 which are not internally connected. Respect always the polarity +/-.




Fig. 1. NÍTID passive connectors



It is strongly recommended to use a two-conductor high quality wire, non-shielded and two-coloured. We recommend using a minimum section of 4 mm² for each conductor. Avoid long wire distances as they induce to important power and quality losses.

2.2. Configurations

2.2.1. Full-range stereo configuration

Connect each output of the amplifier LEFT/RIGHT to each cabinet using two independent wires.




Fig. 2. Full-range stereo configuration

2.2.2. Full-Range parallel stereo configuration

Connect the amplifier's output to the Speakon's input of the first cabinet, always respecting the polarity positive +1, negative -1. Then, make a bridge from the first cabinet to the second one.




Fig. 3. Full-range parallel stereo configuration

2.2.3. Passive configuration with subwoofer

There will be times when you will be interested in reinforcing your NITID Systems with subwoofer units, in passive mode. In this case only one amplifier will be used for the whole system.

Connect one of the outputs of the amplifier to the subwoofer through a wire. Then, make a bridge from the link Speakon connector of the subwoofer to its respective mid-high top unit, always respecting the correct polarity between both systems. Do the same with the other channel.

It is also correct, if the installation requires so, to make the connection in the opposite way, that is, from the amplifier to the top cabinet and then to the subwoofer.




Fig. 4. Passive configuration with subwoofer

2.2.4. Bi-Amplified configuration with subwoofer

A wire with the maximum available section (4mm² minimum) should link the low frequencies output channel of the amplifier to one of the subwoofers. Two subwoofers can be also connected by bridge one to another, as long as the polarity is strictly respected.

Connect the other output of the amplifier to the Full-Range cabinets.

It is also possible to use only one amplifier for the low reinforcement, connecting each one of the subwoofers to the two outputs of the amplifier and consequently, connecting the Full Range cabinets to a second amplifier.




Fig. 5. Bi-amplified with subwoofer configuration (option 1)




Fig. 6. Bi-amplified with subwoofer configuration (option 2)




In order to allow a bridge connection between cabinets, each one of them has been provided with two Speakon connectors that allow the Input / Output function indistinctly. Terminal Pins +1/-1 must be always used, disregarding the +2/-2 which are not internally connected.

3. MOUNTING AND PLACEMENT

For a proper installation of the acoustic cabinet systems, it is strongly recommended to carefully read the following advices.

3.1. Placement



When possible, cabinets should be located in a high position, slightly inclined to the audience. If the loudspeakers are located too low, the listeners at the end of the room will not hear a good sound quality.

Fig. 7. Flying placement

3.2. Rotatable logo

All grille's logo can be rotated.

3.3. Flying

Only experienced people should fly speaker cabinets. Extreme care should be taken to assure the load bearing capabilities of the structures where the cabinets will be placed. Hanging hardware (as chains, eyebolts, lock pins...) should be regularly inspected and replaced if in doubt.

3.3.1. Vertical flying with HR-LU bar and HR-LU/GT

For the S6LP, use HR-LU or HR-LU/GT flying bar for vertical flying. Refer to "HR-LU instructions manual" and "HR-LU/GT instructions manual" for more information.




Fig. 8. HR-LU and HR-LU/GT flying bar for S6LP

3.3.2. Vertical flying with SP-6N

For the S6LP, use SP-6N bracket. Refer to "SP-6N instructions manual" for more information.




Fig. 9. SP-6N bracket for S6PL

3.3.3. Vertical flying with SP-WHR

The SP-WHR is an optional accessory for mounting on wall (vertical orientation) one unit of S6LP. Refer to “SP-WHR instructions manual” for more information.




Fig. 10. SP-WHR bracket for S6PL

3.3.4. Vertical flying with RB-S bar and RB-S/GT

For the S6LP, use the RB-S or RB-S/GT flying bar for vertical flying. Refer to “RB-S instructions manual” and “RB-S/GT instructions manual” for more information.




Fig. 11. RB-S and RB-S/GT flying bar for S6LP

4. TECHNICAL FEATURES

	S6LP
Impedance	
Nominal	8 Ω or 16 Ω
Power	
R.m.s	100 W
Program	200 W
Connectors	1 x Speakon NL4MP input 1 x Speakon NL4MP link
Audio Performance	
Frequency response (-10 dB usable bandwidth)	63 Hz – 20k Hz
SPL (1W / 1m)	92 dB
Nominal directivity (-6dB)	70° x 70°
Components	
LF	1 x 6" neodymium woofer (1.5" voice coil) with carbon fibre cone
HF	1 x 1" PEN diaphragm neodymium compression driver
Cabinet	
Type	Bass-reflex
Height	400 mm
Width	230 mm
Depth	250 mm
Weight (net)	6.4 Kg
Material	Multilayer birch plywood
Finish	Hi-resistance black / white matt Polyurea coating. 1.5 mm steel front grille with black acoustic mesh

Note: Specifications subjected to change without prior notice.



*Great sound
from Barcelona
since 1972*

The **NÍTID** loudspeaker systems have been designed,
engineered and manufactured in Barcelona – SPAIN
by

Amate Audio S.L.

Perpinyà, 25 · Polígon Industrial Nord · 08226 Terrassa
T. +34 93 735 65 65 – F. +34 93 735 60 48 –
info@amateaudio.com

R&D and FACTORY:
Violinista Vellsolà, 18 · 08222 Terrassa
T. +34 93 736 23 90 – F. +34 93 786 47 00

Barcelona – SPAIN

www.amateaudio.com