



*Great sound  
from Barcelona  
since 1972*

[www.amateaudio.com](http://www.amateaudio.com)

# **User's manual** ***Manual de usuario***


# **PA-2010**

**Pole mount adaptor M20-M10**  
***Adaptador pole mount de M20 a M10***

**September 2018**


The PA-2010 is an optional accessory to adapt an M20 thread distance rod bar to the X21T / X21D / X218W3K / X218D / N218W / N218WP subwoofers. These subwoofers include top M10 socket.


*El PA-2010 es un accesorio opcional para adaptar una barra de soporte con rosca M20 a los subwoofers X21T / X21D / X218W3K / X218D / N218W / N218WP. Estos subwoofers incluyen pletina superior de M10.*




1- Screw the PA-2010 adaptor to the M10 top socket of the subwoofer.

*Roscar el adaptador PA-2010 a la pletina superior de M10 del subwoofer.*





2- Screw the distance rod bar to the PA-2010 adaptor.  
*Roscar la barra de soporte al adaptador PA-2010.*



3- Place the “top” acoustic cabinet over the distance rod bar.  
*Colocar la caja acústica “top” encima de la barra de soporte.*

